



System Component List

Panasonic Components

REF	CODE	NR	DESCRIPTION
H1	WH-UDZ05KE5	1	Outdoor unit [05, E5]
H2	WH-ADC0309K3E5	1	All-in-one indoor unit (2) [0309, E5]
H9	PAW-A2W-TSRT	1	Room sensor (if needed) (1)
E64	CZ-TAW1B	1	Wireless/Wired control of the heat pump (optional)
E36	PAW-A2W-TSOD	1	Outdoor air sensor (optional)
	PAW-GRDBSE20	1	Outdoor unit base ground support (optional)
	CZ-NE2P (single fan models) / CZ-NE3P (twin fan models)	1	Base pan heater (optional)

Third Party Components

555	CODE		DESCRIPTION
REF	CODE	NR	DESCRIPTION
H5	Backflow	1	Mandatory for France and Belgium, optional for other countries
H6	Expansion vessel	1	if needed
Н8	Overflow valve	1	To be defined according to the system requirements
H9	Room thermostat	1	if needed (1)
H21	Cold water expansion vessel	1	To be defined according to the system requirements
H23	Safety valve	1	if needed (3)

Footnotes

1	Select room thermostats or room sensors according to the selected circuits control.
2	For normal operation, water pressure reading should be between 0.5 bar and 3 bar
3	Inside the AiO unit there is a safety valve with maximum operating pressure 8 bar

LEGEND – Refrigerant Split System

Panasonic

	nd for the hydraulic part
H1	Refrigerant Split heat pump outdoor unit (provide outdoor unit drain)
	All in One indoor unit: the All in One indoor unit consists of
	domestic hot water 185 litre tank, DHW temperature sensor, 3 way
H2a	valve and heat pump indoor unit. The All in One must be installed
	inside the building. The Y magnetic filter and the flow meter are
	included in all K generation heat pumps.
	All in One 2 zones indoor unit: the All in One indoor unit 2 zones
	consists of domestic hot water 185 litre tank, DHW temperature
	sensor, 3 way valve, heat pump indoor unit, one mixing valve, a
H2b	water pump, a water sensor and a water filter for the mixed circuit
	(top part of the unit). The All in One must be installed inside the
	building. The Y magnetic filter and the flow meter are included in al K generation heat pumps.
	The refrigerant inside the HP and in the connecting pipework is
H3	R32.
	Remote controller of the Heat pump. Dual remote controls may be
H4	used (optional).
H5	System charge and backflow device
	Expansion vessel: every HP has a 10 litre expansion vessel that
H6	will cater for 200 litres at 55°C in the fully open heat pump circuit.
110	Any variation, greater than the specification stated, will require a
	secondary expansion vessel added to the system.
H7	Electrical connections: to be defined when the hydraulic scheme
110	and the system control logic have been selected.
H8	Automatic bypass valve
110	Optional thermostat: every circuit can be controlled with one
H9	optional thermostat, with one room sensor or with the remote controller (CZ-RTW1 additional controller for additional circuit).
	Buffer tank / Volumiser: in the open primary circuit (when all
	heating – cooling circuits are closed) it is recommended a minimum
H10	water volume of at least 30 litres up to and including 9 kW units
	and 50 litres for 12 (kW stated is nominal heating capacity of the
	heat pump A7/W35).
	Heating/cooling circuit: If the HP is connected directly to the
	system, the minimum water flow rate must be guaranteed. Provide
	an automatic bypass valve (recommended 1" diameter) or a 3-way
H11	diverting valve on hydronic indoor units (fan-coil, duct unit etc.) or a
	thermostat must be removed to ensure sufficient flow. If you have floor heating provide a safety thermostat (for heating mode) and a
	dew-point sensor (for cooling mode).
H12	Optional PCB - CZ-NS5P - needed for this scheme
H13	Mix valve with 3 points control
1113	Secondary water pump: they must be chosen according to the
H14	system hydraulic performance.
H15	Boiler
H16	Solar panels
1110	
H17	l Solar numn
H17	Solar pump
H18	Pool pump
H18 H19	Pool pump Heat exchanger for the swimming pool (to be sized)
H18 H19 H20	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool
H18 H19 H20 H21	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water)
H18 H19 H20	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment
H18 H19 H20 H21	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar
H18 H19 H20 H21 H22	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure.
H18 H19 H20 H21 H22	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve
H18 H19 H20 H21 H22	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve Security valve Thermostatic mixing valve (optional)
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve Security valve Thermostatic mixing valve (optional) Pressure regulator
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve Security valve Thermostatic mixing valve (optional) Pressure regulator Boiler circuit pipes
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve Security valve Thermostatic mixing valve (optional) Pressure regulator Boiler circuit pipes Solar panels circuit pipes
H18 H19 H20 H21 H22 H23	Pool pump Heat exchanger for the swimming pool (to be sized) Swimming pool Expansion vessel (cold water) Sanitary equipment Inside the All in One unit there is a safety valve with a 8 bar maximum operation pressure. Shut-off valve Non-return valve Security valve Thermostatic mixing valve (optional) Pressure regulator Boiler circuit pipes

Legend for the electric part Main board PCB: the maximum cable length for sensor inputs is 30					
E27	2 way valve: open for heating (O+N) and close for cooling (C+N)				
E28	3 way valve: open for DHW (O+N) and close for heating/cooling system (C+N)				
	Optional thermostat 1: every circuit can be controlled with one				
E29	optional thermostat (E29 for one zone and E29 and E54 for 2 zones), with one room sensor (E37 for one zone or E40 and E41				
F20	for 2 zones) or with the remote controller (E 33, 1 or 2 circuits). Booster heater				
E30 E31	Extra pump control				
E32	ON/OFF boiler or deice output (dry contact)				
E33	Remote Controller: the K generation heat pump remote controller can be used as a room thermostat for two circuits. The cables maximum length is 50 meters.				
E34	External ON/OFF (dry contact)				
E35	DHW tank sensor				
E36	Outdoor air sensor (optional)				
E37	Zone 1 room sensor (see point E29)				
E38	OLP booster heater: on the OLP contact must be put a jumper if external booster heater is used and controlled by Panasonic heat pumps.				
E39	Optional PCB: the maximum cable length for sensor inputs is 30 meters and the maximum cable length for outputs and other inputs is 50 meters. If the optional PCB (CZ-NS5P) is installed, the room sensor 1 and the extra pump control contacts of the main PCB are disabled				
E40	Zone 2 room sensor (see point E29)				
E41	Zone 1 room sensor (see point E29)				
E42	Buffer tank sensor				
E43	Pool water sensor				
E44	Water sensor zone 2 (see point E29)				
E45	Water sensor zone 1 (see point E29)				
E46	Demand signal (0-10 V)				
E47	Solar sensor				
E48	Smart Grid signal: the 2 contacts can increase the set-point for DHW and heating or cooling if there is energy production from the PV panels. The 2 input contact can be also used to control a bivalent system with boiler and heat pump using an external control. The 2 options exclude one another.				
E49	Heat / cool switch				
E50	External compressor switch				
E51	Mixing valve zone 2				
E52	Mixing valve zone 1				
E53	Optional thermostat 1 (see point E29)				
E54	Optional thermostat 2 (see point E29)				
E55	Pool pump				
E56	Solar pump				
E57	Error signal (dry contact				
E58	Pump zone 1				
E59	Pump zone 2				
E60	All in One indoor unit power supply				
E61	All in One indoor unit power supply 1 - main				
E62	All in One indoor unit power supply 2 - heaters				
E63	Connection to the outdoor unit: the outdoor unit power supply comes from the All in One indoor unit, so it is not necessary to bring a direct power supply to the outdoor unit.				
E64 CZ-TAW1B is a device that can allow the remote control of the pump using a LAN or Wifi connection to the modem. Using thi device the HP can be online on the Aquarea Smart Cloud web (https://aquarea-smart.panasonic.com).					